

USING A NOTEBOOK/LAPTOP COMPUTER

If a notebook/laptop computer is to be used with the SMART Board, you will need to complete the steps below to have the information display on the SMART Board.

- ✦ You can connect to a notebook computer and have the information display on the SMART Board without installing the SMART Board software.
- ✦ Disconnect the **Data Cable** from the back of the desktop computer.
- ✦ Connect the **Data Cable** to the notebook computer.
- ✦ Press the **Notebook Computer Button** at the front of the SMART Board.
 - ✦ This set of buttons is located next to the **Start** button for the SMART Board.
 - ✦ In order to activate the option, press the triangle shape button at the top of the notebook computer image.
- ✦ Connect the **Video Cable** that is located at the back of the **SMART Board**.
- ✦ Press the **FN** key on the keyboard of the notebook computer.
- ✦ Press the function key that has either a **CRT/LCD** button or the one that has a notebook computer image.
 - ✦ This key can be different depending on the make of the computer.
 - ✦ Just look for one of the images on the function keys on your computer keyboard.
- ✦ This should then display the information that is on the notebook onto the SMART Board screen.
- ✦ You are now ready to start using the **SMART Board**.